

ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0008 / P0009 / P0010

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

**NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THESE INSTRUCTIONS.**

Contents of Spare Parts:



1. Take out the socket with cord, thread the cord through cap nut, plate, canopy, nipple, hex nut, washer and two holes of the strain relief.
2. Measure the desired length of the cord (A) from the canopy to the top side of the cap nut and leave an additional 9" of cord (B) above the canopy (include the canopy). Then cut off the unnecessary cord. (See Fig.1)
3. Adjust strain relief at 9" position from the top of the cord.
4. Mark the 3" of cord (C) from the top of the cord (B). Use a knife to peel off the insulation of the cord (C) carefully to expose the 3 wires on the inside. (See Fig.1)

Caution: Cutting too deep may cut off the three inside wires and destroy the insulation surface of the three inside wires.

5. Peel off the 3 wires from the top about 3/8" long(D) to expose the copper for wiring.
6. Attach the nipple to the mounting strap, then secure it with a washer and hex nut.
7. Attach the mounting strap to the outlet box by using two mounting screws.
8. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
 - a. The clear wire marked "L" from the fixture to the black wire from the power source.
 - b. The clear wire with white line and marked "N" from the fixture to the white wire from the power source.
 - c. The clear grounding wire with green line from the fixture to the green grounding wire from power source.
 Carefully put wires back into the outlet box.
9. Pull the cord (A) down slightly until the strain relief touches hex nut.

Note: Adjusting the strain relief of the canopy can decrease or increase the length of cord that is exposed.
10. Attach the canopy and plate to the mounting strap. secure them with cap nut.
11. Install a bulb (not included). See relamping label at socket area or packaging for maximum allowed wattage.
12. Attach the sphere shade onto the glass holder, secure it by pressing the clip.
13. Turn on the power at the main fuse or circuit breaker box.

